DMV High Performance Replacement Air Filter

1.Take the air filter out form the inner box .Use the compresses air to remove and clean out the dirt from each side.

2.Apply the DMV cleaner onto both side evenly . (CAUTION: the use of any other cleaning solution or method could damage the filter !!!) i.e use of water, steam , chemicals, gasoline, transmission fluid , motor oil, lightweight oil, or any diesel fuel , as they are not designed to clean non-woven material air filter.

3.Allow cleaner to soak into both sides of air filter for about 10 minutes : afterward use the compressed air yet again to remove the dirt. (repeat step 3 and step 4 if necessary , until it's clean and tidy.)

4.Let the air filter dry naturally or use the compressed air to dry it.(CAUTION: Other drying method could damage the filter)

5.Apply certain amount of DMV air filter cleaning oil evenly onto each side of the air filter (CAUTION: Over oiling the air filter may interfere the performance of engine.)

6.Reinstall the air filter back into the inner box and then be sure that the inner box is securely fastened.DMV strongly recommended to service the air filter at least every 5000KM in order to maintain optimum performance.

Strongly recommended that air filter must be checked and cleaned oftenly especially when you're riding on any high-speed or off-road circumstances.